

## INSTALLATION INSTRUCTIONS

1. Turn power off. Loosen the screws (E) of the connector (D) by turning them counterclockwise with a screwdriver.
2. Insert your electrical wire (F) into the hole (G) of the terminal. Follow color codes: brown to brown, blue to blue, yellow-green to yellow green.
3. Position the distribution box on the ceiling (A) near the electrical supply wires so the wires are hidden behind the distribution box (A). Fix box (A) on the ceiling by boring screws into the holes (B).
4. Mount the accent cover (H) to the luminaire support by inserting the guide pin (I) to the hole (C). This will align the holes (J) of the distribution box to holes (K) of the cover (H). Fix using bolts (L).
5. Install the G9 bulb (M1) (use the correct no. of watts as indicated in the sticker) into the lampholders (M2).
6. Install bottom cover (N) by inserting tube end (O) to hole of the cover (P). Lock in place using locknut (Q) and ball (R) by turning them clockwise.
7. When changing the bulbs, be sure to turn off power and let the bulbs and the metal parts surrounding them to cool off before touching any part of lamp.
8. Do not touch any metal part of the lamp surrounding the bulb while the lights are turned on. It can get very hot and cause injury.

