


H5540. 01



1. This light fitting operates at a normal supply voltage of 220V-240V.
2. Make sure the power is off before installing the luminaire.