


399-5 /699-5


Ver:1.0 -13.11.17







	PARTS LIST	Qty			
A		5	Е	L	1
В		5	F	••••	1
С	₩	10	G	08080808080808080808080808080808080808	5
D	C8080808080808080	5	Н		20



SAFETY INFORMATION: (Please retain for future reference)

- · Always turn off the mains supply before commencing the installation of this fitting .
- This is a Class 1 product and requires an Earth connection ⊕ 230 (240) Volts 50Hz AC.
- This product must be installed in accordance with the national building regulations, if in doubt consult a qualified electrician.
- We do not recommend any modifications of the fitting (*with the exception of cable and chain shortening) as this may invalidate the warranty and render the fitting unsafe.
- This fitting is suitable for installation in Indoor locations only .
- · Do not mount the fitting in a damp atmosphere.
- Do not stare at the operating lamp when using LED lamps .
- The Luminaire should be positioned so that prolonged staring into the luminaire at a distance closer than 0.2m is not expected when using LED lamps .
- Ensure sufficient access to the fitting to enable safe maintenance.

LAMP INFORMATION:

- We recommend LED lamps only.
- The fitting is suitable for dimming when using dimmable LED lamps.

Do not exceed the maximum rated wattage stated on the lamp holders **MEUTRAL - Possible colours: Black or (Blue) *** 4th Block for "Loop In" system (if required) *** **Total Colours: Black or (Blue) *** **Tota

ADDITIONAL INFORMATION:

- If the height of the fitting requires shortening we recommend that the removal of any chain links and supply cable that may need to be cut to a shorter length is done by a qualified electrician (Remember to mark clear cable with Live, Neutral and Earth prior to removing from the terminal block). The length of the supply cable CANNOT be increased.
- During transit it is possible that the Acrylic arms may be out of alignment, it is possible to move the arms up or down to make them straight, take care not to bend the metal bracket that connects the arms to the centre column too much.

AFTERCARE AND MAINTENANCE:

- Always disconnect power supply when servicing or cleaning.
- Clean only with a dry or slightly damp cloth.
- Do no use any abrasive cloths or cleaners as this may damage the product

