Important information

novoform

Opladning
Insæt et TYPE C stik for at oplade - indikatoren lyser rødt.
Når lampen er fuldt opladet, vil indikatoren lyse grønt.
En fuld opladning tager 6-7 timer med en 5V/2A oplader.
Opladningstiden kan variere, hvis en anden type oplader anvendes.

Brug
Tryk kortvarigt på knappen for at skifte lysstyrken mellem 0% / 30% / 70% / 100%.
Tryk langvarigt på knappen for at slukke lampen. Lampen vil tænde på samme lysstyrke som da den blev slukket.
Kun til indendørs brug. Lampen kan tages med udenfor, men skal opbevares indendørs.

Vedligeholdelse af batteriet - vigtigt!
Lampen har to 21700 Li-ion batterier med en samlet kapacitet på 8000mAh.
Batteriet bør aldrig aflades fuldstændigt, eller efterlades ubrugt i lange perioder, da det kan beskadige batteriet. Vi anbefaler at oplade batteriet fuldstændigt minimum én gang hver 10. måned. Hold batteriet væk fra ild og væsker.

Tekniske data

Max. opladningsstyrke:	DC 5V/2A
Opladerstik:	TYPE C
Opladningstid:	Typisk 6-7 timer (5V/2A)
Batterikapacitet:	8000mAh
Lysudbytte:	125lm
LED pære watt:	3W
LED pære volt:	12V DC
Driftstid:	Op til 10 timer (ved 100% lysstyrke)

Rengøring
Afbryd elektriciteten og rengør med en tør klud.

CE IP44

Beskyt miljøet
Undlad venligst at bortskaffe dette produkt sammen med almindeligt husholdningsaffald - det bør bortskaffes i henhold til de lokale miljølove for affaldshåndtering. Materialerne er genanvendelige i henhold til deres specifikationer. Ved korrekt genbrug af disse materialer kan du gøre en væsentlig indsats for at beskytte miljøet.
Spørg din lokale myndighed på nærmeste genbrugsstation.

Charging
Insert TYPE C plug in the socket to start charging - the indicator will show a red light.
When fully charged, the indicator will show a green light.
It takes 6-7 hours to fully charge the battery with a 5V/2A charger.
The charging time differs when using a different charger.

Operation
Tap button shortly to shift brightness between 0% / 30% / 70% / 100%.
Touch and hold button to turn the lamp OFF. The lamp will turn ON at the same brightness setting as when it was turned OFF.
For indoor use only. The lamp can be taken outdoors, but must be kept and stored indoors.

Maintenance of the battery - important!
The lamp is powered by two 21700 Li-ion battery cores with a combined capacity of 8000mAh.
The battery should never be completely discharged of power or left unused for extended periods - it may damage the battery. We recommend charging it fully at least once every 10 months. Keep battery away from fire and liquids.

Technical data

Max. charging power:	DC 5V/2A
Charging socket:	TYPE C
Charging time:	Typically 6-7 hours (5V/2A)
Battery capacity:	8000mAh
Light output:	125lm
LED bulb wattage:	3W
LED bulb voltage:	12V DC
Runtime:	Approx. 10 hours (at 100% brightness)


Cleaning
Turn off electricity and clean with dry cloth.

CE IP44

Advice for environmental care:
Please don't dispose of this article in normal domestic waste after the end of its lifecycle. Instead, we advise that you dispose of it according to local environmental laws for waste disposal. The materials are recyclable according to their specifications. With the correct recycling of these materials, you can make a significant contribution to environmental protection. Ask your local authorities.

MOOV portable lamp

DESIGNED BY JOHANNES LINDNER




Tillykke med din nye MOOV lampe. Vi håber, at du vil nyde at bruge dette produkt og følge disse instruktioner for at sikre korrekt brug og installation. Novoform er ikke ansvarlig for fejl eller skader forårsaget af ikke at følge disse instruktioner korrekt.


Congratulations on your new MOOV lamp. We hope you will enjoy using this product and follow these instructions to ensure correct use and installation. Novoform is not responsible for any faults or damages caused by not following these instructions correctly.

novoform


1




2




3



4



5



6

