


ROBY CEILING SURFACE

28-Jun-2019








1 Keep the inner edge upwards 3 ø145 ROBY 2.6 & ROBY 3.5 have the same base plate 101 mounted. ø110

DIMENSIONS




MOUNTING INSTRUCTION

(1) Remove the base plate from the ROBY and mount it on the ceiling with screws. Also disconnect the fall protection. ROBY 2.6 and ROBY 3.5 have the same base plate.

POWER CONNECTION

Interior connection: STANDARD version



- Put the ROBY cover on top of the fixture before clicking it on the base plate
- 4 Connect the fall protection back to the base plate. Then attach the ROBY to the base plate by clicking the 3 foreseen pins into the holes

The light source of the integrated LED is not replaceable; When the light source reaches its end of life the whole luminaire should be replaced.



Caution, risk of electric shock

ROBY 1.6

ROBY 2.6

LIGHT COLOUR 2700K | >90CRI | 1680lm 3000K | >90CRI | 1800lm

ø187

ROBY 3.5