

## Assembly manual for 1804 series



1. Unscrew the nipple.



2. When the nipple is unscrewed the GU10 bulb, with the socket, will slide out of the lampshade.



3. Grasp the GU10 socket with your fingers.

4. Unscrew the bulb.

5. Screw in the new bulb.



6. Slide the bulb, with its socket, back into the lampshade.



7. Screw the nipple back.