


SAFETY INFORMATION:

(Please retain for future reference)

- Always turn off the mains supply before commencing the installation of this fitting .
- This is a Class 2 product and requires no Earth connection – 230 (240) Volts – 50Hz AC.



- This product must be installed in accordance with the national building and wiring regulations, if in doubt consult a qualified electrician.
- Do not stare at the operating lamp .
- This fitting is suitable for installation in Indoor locations only .
- Ensure sufficient access to the fitting to enable safe maintenance.
- The Luminaire should be positioned so that prolonged staring into the luminaire at a distance closer than 0.2m is not expected
- Do not modify or alter any product before or after installation. This may Invalidate your warranty and may render the product un-safe.

LAMP INFORMATION:

- The LED lamps are not replaceable , when the lamps reach the end of their life the whole luminaire shall be replaced .
- The LED lamps and chip board are not removable

DIMMING:

- This fitting maybe dimmed when using a compatible LED dimmer switch

ADDITIONAL INFORMATION:

- The fitting has a 'rise and fall' mechanism to allow height adjustment(7) . To shorten the fitting hold each wire in turn and gently push upwards to the desire height, the support wire will freely move into the ceiling can. If required the fitting can be lengthened back to the original height, push the small metal release pins in individually, this will release the clamp and allow each support wire to become free to lengthen

AFTERCARE AND MAINTENANCE:

- Always disconnect power supply when servicing or cleaning.
- Clean only with a dry or slightly damp cloth.
- Do no use any abrasive cloths or cleaners as this may damage the product .



This symbol on the product indicates that this product must not be disposed of with your normal household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of wasted electrical and electronic equipment. For more information about recycling please contact your local council or your household waste disposal service or the shop where you purchased the product.