

The first fresh air floor lamp has everything you need to eliminate odours, germs, viruses and bacteria: an OZONOS Aircleaner inside the lampshade, a simple function and an innovative, modern design. Experience fresh air in a different way.

QUICK START GUIDE

FLOOR LAMP »HAILEY« STARTUP

STARTUP AND OPERATION

- 1 Assemble the floor lamp „Hailey“ as described on the next page.
- 2 Connect the „Hailey“ floor lamp to an earthed 230-volt mains connection via mains plug.
- 3 Press the footswitch or the remote control to activate the Aircleaner.
- 4 A soft buzzing can be heard.
- 5 To deactivate, press the footswitch or the remote control again.

AVAILABLE COLOURS



ATHENE CREME



JEANS GREY



LINEN NATURE

more on request



DO YOU HAVE ANY QUESTIONS? CONTACT US NOW.

OZONOS GmbH

Friedensstraße 2-6
5020 Salzburg · Austria

T +43 (0) 662 / 238 288 - 0
F +43 (0) 662 / 238 288 - 99

M frischluft@ozonos.at
W www.ozonos.at

INSTALLATION GUIDE

FLOOR LAMP »HAILEY«


IMPORTANT INFORMATION

This manual describes the correct installation of the device. Please follow all steps properly and observe warnings and notes!



STEP 1

Pay attention to the correct alignment of the pre-drilled holes.



STEP 2

Mount the cover on the bottom of the foot.



STEP 3

Attach the top cover.



STEP 4

Then place the lampshade on top.

TECHNICAL DATA

DESCRIPTION LED FLOOR LAMP:

Floor lamp, with LED strip and integrated OZONOS AC-I

DIAMETER	Ø600 mm
HEIGHT	1740 mm
LED	24V/230V
54W, 4950lm, 2700K, CRI 90	
Driver incl., Euro plug, footswitch – dimmable SWF RAL 9005 fine structured black, acrylic white satined	

DESCRIPTION OZONOS AC-I

Aircleaner suitable for permanent use

MEASUREMENTS	L 400mm · Diameter 130mm · Weight 2,7 kg
UV-C BULB	1 x 8 Watt
INPUT POWER	14 Watt
UV-C BULB	Durability of the UV-C bulb: 8.000 operating hours
AIR FLOW RATE p.h.	55 m ³
VOLUME	37 db
REMOTE CONTROL	yes