

Assembly & Care Guide

Margin Pendant Lamp Ø50 / Ø70

The Margin Pendant Lamp is carefully made, making every item unique. The shade is made of a natural material and differences in expression may occur, such as smaller marks and minor deviations.

SAFETY INSTRUCTIONS

Please read the instructions carefully and keep them for future reference. New Works Aps is not responsible for any faults or damages caused by not following the instructions correctly.

Turn off electricity at the main circuit breaker panel before beginning the installation. Installation is to be carried out only by a qualified electrician. It is important that all wires are connected - when unpacking the box, be careful not to pull wires, as this may result in a bad connection.

This lamp must be permanently wired into the electric system. Different ceiling materials require different types of fittings. Always choose screws and plugs that are suited to the ceiling material.

The lamp is only intended for indoor use. Consult a professionally qualified electrician if any doubt. Follow the guidance **220-240V~ 50/60Hz - E27 LED Max. 12W or E27 Max 60 W**
The light source and lamp exterior may get hot after prolonged use.

Do not subject the lamp to any shock while lit as this may cause the lamp to brake.

Keep the product out of children's reach. Dispose of the packaging and do not allow children to play with it. Do not modify the product in any way.

CLEANING

Turn off the electricity before cleaning the lamp. Wipe the lamp shade with a soft dry or moist cloth. Do not use any abrasive cleaning tools, and never use strong cleaning agents such as household glass cleaner, white spirit or turpentine.

MORE INFORMATION


For more information such as product overview, material description and disclaimers - please visit our website at **www.newworks.dk**. If you have any questions or comments, please do not hesitate to contact us at **info@newworks.dk**.

NEW WORKS.

Assembly & Care Guide

Margin Pendant Lamp Ø50 / Ø70


Read the instruction carefully and do not connect the electricity until the lamp is fully assembled.
Warning all wires are connected - when unpacking the box, be careful not to pull wires, as this may result in a bad connection. Unpack and place all parts on a levelled and stable surface.



NEW WORKS.

Assembly & Care Guide

Margin Pendant Lamp Ø50 / Ø70




1. Place the light fixture (E) inside the shade (H) and insert the cable through the metal ring in the center of the shade. Use the washer (F) from the plastic bag to secure the light fixture inside the shade. Run the cable through the tube (G) and mount it on top of the washer. Tighten the set screw in the tube to secure the cable.
2. Install the light bulbs - E27 LED Max. 12W or E27 60W (not included.) Run the cable through the hole in the lid (I) and place the lid on top of the shade.

NEW WORKS.

Assembly & Care Guide


Margin Pendant Lamp Ø50 / Ø70



3. Place the ceiling fitting (A) in the desired position and mark the drilling holes. Drill holes and mount the fitting. Make sure to use plugs and screws appropriate for the ceiling material.

4. Run the cable through the nut (C) and the canopy (B) before inserting it into the Ceiling fitting.

5. Connect electricity by installing both cables, natural (N) and live (L) in the terminals (D). Consult a professionally qualified electrician if any doubt.



6. Move the canopy (B) back up to cover the fitting


7. Mount the nut (C) to secure the canopy.

8. Tighten the set screw in the nut to secure the cable.

NEW WORKS.

Assembly & Care Guide

Margin Pendant Lamp Ø50 / Ø70



9. After the lamp has been installed place the small shade (J) inside the large shade and use the long tube (K) to secure it. Make sure the split lines are aligned.

10. Turn on the electricity again at the main circuit breaker panel.

NEW WORKS.