

# Instruction Manual

## TECHNICAL SPECIFICATION

Model Number	MT69065	MT69066
Series Name	ZELLA NEO	
Color	Grey	
Inclusive Light Source	MT69067	MT69068
Light Source Wattage	7,5W/4,5W	7,5W/4,5W
Light Source Energy Efficiency Class<X>	E	
Lumen Containing Product	710/425lm	750/450lm
Lumen Light Source	950/570lm	1000/600lm
Beam Angle (°)	120	
Voltage	AC220-240V	
Frequency	50/60Hz	
CCT	3,000K	4,000K
CRI	Ra 80	
Lifetime L70 B50	35,000h @ Ta25 C	
Switching Cycles	>100.000x	
Power Factor	>0,5	
Dimensions LxWxH (mm)	165x120x65	
IP Rating	IP54	
IK Rating	IK08	

### Part List:



2 x Screw



2 x Bolt



2 x Dowel



1 x Strain relief



2 x Water proof gasket

### CAUTIONS:

- Read the entire manual carefully before installation and operation.
- Installation or replacement should be performed only by licensed and qualified electricians.
- Switch OFF the power source before installation, replacement and cleaning. ⚠
- Before replacement of the luminaire, turn it off and allow it to cool down.
- DO NOT disassemble the inner part of the luminaire. Doing so may result in luminaire damage or malfunction.
- The minimum safety distance from the illuminated object is 0,1m. ⚠
- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.
- The manufacturer accepts no liability for any damage resulting from the misuse of the luminaire or from when is it used with inappropriate equipment.
- This product contains a light source of energy efficiency class E.
- Important warning for drilling in walls: before drilling, make sure that there are no gas and water pipes or power lines behind or near the drilling spots. Drilling and mounting should be performed only by qualified personnel. Be sure to pay attention at the condition and material of the walls, as the mounting material is not suitable for all wall types. Please inquire about recommended screws and raw plugs for your wall type and wall condition. The manufacturer accepts no liability for improper wall raw plug mounting and the herefrom resulting damages.
- Consult your dealer if you have any enquiries.

# Instruction Manual

## INSTALLATION:

1.

**OFF**

2.

Use a suitable tool to open the specified cable entries.

3.

Use the backboard or legs as a template in order to mark and drill the appropriate fixing holes on the ceiling/wall. Secure the backboard with backboard or legs with raw plugs and screws on the ceiling/wall.

4.

**N** Blue  
**E** Yellow/Green  
**L** Brown/Black

Guide the connection cable through the selected opening. Connect the mains cable to the connection terminal.

5.

Secure the mains cable with the strain relief and the bolt on the luminaire housing.

6.

Slide the toggle switch on the LED module to the desired position before mounting to set the desired lumen value.

7.

Connect the plug of the LED-module to the socket of the luminaire housing. Press the cover of the LED-module evenly onto the lower part of the luminaire until the clips provided snap into the connection points.

8.

**ON**

### Replacing the LED-module

Separate the cover and the former LED module with a screwdriver vertically through the notches on the housing. Carefully remove the LED module from the housing and pull the connector between the LED module and the connector on the housing straight out to separate the LED module from the housing.

## ATTENTION:

- Designed for indoor and outdoor applications.
- The operating temperature of the luminaire is -30° C to +40° C.

## Correct disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

